

Murano Glass Cosmos Chandelier

Assembly Guide



Thank you for choosing In Common With. Please confirm that you received all of the components pictured in this guide, and reach out to us if anything is missing. It's rare, but it happens. We hope you enjoy your fixture. With proper care, it should last a lifetime.

Have questions? Please contact us at support@incommonwith.com.



CAUTION!

Electrical shock risk. Turn off electrical power at the main fuse box or circuit panel before beginning installation, servicing the light, or installing accessories. We recommend working with a qualified electrician familiar with the type of work you'd like done.


ATTENTION!

Risque de choc électrique. Coupez l'alimentation électrique au niveau de la boîte à fusibles principale ou du panneau de circuits avant de commencer l'installation, l'entretien de la lumière ou l'installation d'accessoires. Nous vous recommandons de travailler avec un électricien qualifié familier avec le type de travail que vous souhaitez effectuer.


Murano Glass Cosmos Chandelier
Components



Stem




Canopy Assembly



Canopy Backplate




Stem Screws (3)




Arm Assembly



Murano Glass Orb 4 Diffuser (3)




Class 2 Power Unit




Hardware Pack

Step 1




Before beginning installation, turn off electrical power at the main fuse box or circuit panel.

Step 2




Gently feed the wires from the Arm Assembly through to the top of the Stem. Slide the Arm Assembly into the Stem.

Step 3



Align the holes of the Arm Assembly with the holes of Stem. Use the hex key found in the hardware pack to secure the Stem screws into the Stem.

Step 4



Use only with Class 2 Power Unit with output DC24V constant voltage.
Connect the junction box wires to the Class 2 Power Unit with Wago clips:


White → Neutral

Black → Live

For 0-10V Dimming: Connect pink and purple wires to the same colors dimming system. For TRIAC or ELV Dimming: Cap the pink and purple wires with Wago clips. If needed, strip 3/8" of insulation from each wire before connecting.


If you are using a remote driver, move on to the step 6.

Step 5




Nest the Class 2 Power Unit into the junction box with the red and blue wires accessible. Ensure easy access to the wires by feeding them through the central opening in the Backplate. Mount the Backplate to the junction box using a Phillips head screwdriver to tighten the mounting screws.

Step 6




Gently rotate the Canopy cover counter-clockwise to remove it from the Canopy base.

Step 7




Rest the Canopy cover on the fixture during the assembly. Be careful not to scratch the fixture.

Step 8



Feed the wires from the Stem into the Canopy base. Gently rotate the Stem clockwise to secure it into the Canopy base.

Step 9



Use Wago clips to connect the Class 2 Power Unit wires to the fixture:


Blue/Black → Neutral

Red → Live

Green/Yellow → Ground


If needed, strip 3/8" of insulation from each wire before connecting.

Step 10



Mount the Canopy base into the Backplate using a phillips head screwdriver to tighten mounting screws.


Step 11



Gently slide the Canopy cover up the Stem. Rotate the Canopy cover clockwise to secure firmly in place.


Remove the protective paper from the Canopy cover. Discard.

Step 12



Attach the Murano Glass Orb 4s diffusers to the metal hardware by rotating clockwise until fixed in place. Be careful not to overtighten.

Step 13



Turn the power back on at the main fuse box or circuit panel you disabled before installation. Turn on the light :)

Never use scouring pads or abrasive cleaning solutions. If it comes in a bottle, it is bad for your fixture. Instead, we recommend using soft microfiber cloths, which are gentler on our products and the planet.

For Metal: Wipe with a damp or dry microfiber cloth. Please note that our brass is unlacquered, and will darken naturally over time.

For Glass: Wipe clear or colored glass with a damp microfiber cloth. For sandblasted or etched glass, use a dry microfiber cloth. Removable glass shades can be washed carefully in a sink using warm or hot water.

For Ceramic: Wipe with a damp microfiber cloth. Do not submerge in water.

Return Policy

We accept returns for store credit only, minus a 15% restocking fee. We do not accept returns on pieces from the Handmade, Disc, Terra, or Flora series, on the Ceramic or Chromatic Glass Up Down Sconces, or on items that are not in their original condition. Custom and Rush orders are final sale. Please note that shipping charges are non-refundable.

To request a return, email sales@incommonwith.com within ten days of receiving your order. Requests must be approved before a return can be processed. Requests made after ten days will not be accepted.

All products that come in their own box, including but not limited to light bulbs and accessories, must be returned in their original, undamaged box as this is considered part of the product. Once installed, products are no longer eligible for return.

We reserve the right to reject any returned items that do not meet the above requirements. If your return is rejected you will be notified via email.